

SLIDE-OUTS

The pressure angle (PA) on all Lippert Through Frame slide-out gear packs has changed from 14.5PA to 20PA. This will require a change in replacement parts used for through frame slide-outs. See TI 001 to determine the gear rack and spur gear currently in use.

For customers with broken teeth in a gear pack, replacement parts will be a new gear pack (20PA) and an original spur gear (14.5PA). The pressure angle of the spur gear on the new gear pack will not mesh with the pressure angle of the old gear rack. The new gear pack will need to be disassembled, and the spur gear on the new gear pack will need to be replaced with the spur gear **122739**.

To replace spur gear:

1. Remove the roll pin (if equipped).
2. Remove the mounting plate.
3. Remove the spur gear.
4. Replace the spur gear with spur gear **122739**.
5. Reverse the process.

Parts are as follows:

- 2" x 2" Gear Pack Assembly (20PA) - [281331](#) (Fig. 1)
- 2 ½" x 2 ½" Gear Pack Assembly (20PA) - [324869](#) (Fig. 2)
- 2 ½" x 2 ½" Heavy Duty Steel Gear Pack Assembly (20PA) - [123356](#) (Fig. 3)
- Spur gear (14.5PA) - **122739** (Fig. 4)

Fig. 1



Fig. 2



Fig. 3





Fig. 4



SLIDE-OUTS

For customers with broken teeth in a gear rack, replacement parts will be two new inner arms, and two new gear packs. Both inner arms and gear packs must be replaced at the same time in order to maintain timing. The pressure angle of the spur gear on the new gear pack will not mesh with the pressure angle of the old gear rack.

Parts are as follows:

- 2" x 2" Inboard (20PA) - **163778** (Fig. 5.1, Fig 5.2)
- 2" x 2" Outboard (20PA) - **145736** (Fig. 6.1, Fig 6.2)
- 2" x 2" Gear Pack Assembly (20PA) - **281331** (Fig. 1)
- 2 ½" x 2 ½" Inboard (20PA) - **143710** (Fig. 7.1, Fig 7.2)
- 2 ½" x 2 ½" Outboard (20PA) - **143707** (Fig. 8.1, Fig 8.2)
- 2 ½" x 2 ½" Gear Pack Assembly (20PA) - **324869** (Fig. 2)
- 2 ½" x 2 ½" Heavy Duty Steel Gear Pack Assembly (20PA) - **123356** (Fig. 3)

Fig. 5.1




Fig. 5.2




Fig. 6.1





Fig. 6.2



SLIDE-OUTS

Fig. 7.1




Fig. 7.2




Fig. 8.1





Fig. 8.2



As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at www.lci1.com or by downloading the MyLCI app.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.