


SPRINTER HYDRAULIC LEVELING (4PT-3VLV) ASSEMBLY

LEVELING AND STABILIZATION

**Front Leveling
Jacks x 2**




Controller




NOTE: Controller may be found near the front of the coach, normally in a protected enclosure.

Touchpad & Harness



NOTE: Touchpad may be found near the driver.

Hydraulic Power Unit



NOTE: Hydraulic Power Unit may be found in various locations, normally in a compartment.

**Rear Leveling
Jacks x 2**



NOTE: Component locations shown are an approximation and will vary per manufacturer's specifications.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.