

REMOTE LEARN ON SUREPOWER CONTROLLER

****Note - for this process, you have 5-7 seconds to perform these steps or the controller will exit programming mode. ****

STEP 1

Make sure actuators are disconnected.

STEP 2

Press ext on rocker switch for 3-4 seconds until status LED lights **SOLID YELLOW**.

STEP 3

Hit retract 3 times (status LED will blink **YELLOW** with each press of rocker switch.)

STEP 4

Hit ext 1 time (status LED should be solid **RED**) this will mean the controller is in learn mode. Press either button on remote, LED will flash **GREEN**. Remote is now programmed.

STEP 5

Hook actuators back up and complete initialization process and make sure you have a solid **GREEN** status light.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.