


TRIPLE PLAY RAMP DOOR COMPONENTS

DOORS








NOTE: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.



Callout	Part #	Description
A	Varies	Triple Play Ramp Door
B	677782	Triple Play Doorjamb (variant)
	677800	
	760003	

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
C	711511	Controller
D	711594	Touchpad
E	716794	Angle Sensor
F	720116	Key Switch
G	404701	Warning Label
H	434158	Electric Motor, Latch Cinch
I	702192	Electric Limit Switch (with plunger)
J	733491	Drive Sprocket Assembly

TRIPLE PLAY RAMP DOOR COMPONENTS



DOORS



Callout	Part #	Description
K	691995	Electric Motor, Linear Actuator
L	720426	Electric Motor, Right Angle Gearbox

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
M	425585	Wire Harness, Touchpad
N	711716	Wire Harness, Cinch Motor
O	711721	Wire Harness, Key Switch
P	716793	Wire Harness, Angle Sensor

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
Q	711717	Wire Harness, Limit Switch, Right Side
	711718	Wire Harness, Limit Switch, Left Side
R	711719	Wire Harness, Latch Actuator Motor, Right Side
	711720	Wire Harness, Latch Actuator Motor, Left Side
S	721769	Wire Harness, Main Power
T	725233	Wire Harness, Gear Motor (10 ft.)
	736685	Wire Harness, Gear Motor (5 ft.)

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
U	643479	Support Cable, Curbside
	643482	Support Cable, Roadside
V	677795	Cable, Gear Drive Motor, 4.625" L
	677796	Cable, Gear Drive Motor, 57.00" L
W	2315891	Anchor Bracket, Support Cable
X	380282	Snap Retainer Pin, 3/8" x 1 3/8"
Y	383355	Spring, 26.122" FL .283" wire extension
Z	383361	Anchor Bracket, Gear Motor/Drive Cable
AA	390583	Roller Chain

TRIPLE PLAY RAMP DOOR COMPONENTS







DOORS



Callout	Part #	Description
AB	405623	Hidden Hinge, Roadside
	405624	Hidden Hinge, Curbside
AC	677785	Doorjamb Swing Arm, Curbside
	677787	Doorjamb Swing Arm, Roadside
AD	687774	Hanging Release Pull Lever
AE	383368	Plate, 3.63" x 7.00"
AF	383600	Cross Member, 2.625" x 3.788" x .750" x .750"
AG	434156	Mounting Bracket, Cinch Latch
AH	674822	Angle Bracket, 1.35" x .88" x 6.50"
AI	677792	Angle Bracket, 7.00" x 1.50" x 3.75"
AJ	677794	Round Tube, 3.469" x 1.000" x .438"

TRIPLE PLAY RAMP DOOR COMPONENTS




DOORS



Callout	Part #	Description
AK	677862	Standard Connecting Link, #35
AL	692048	Plate, 7.75" x 2.75"
AM	702204	Plate, 7.88" x 2.97"
AN	707133	Torsion Spring, Right Hand
	707134	Torsion Spring, Left Hand
AO	713745	Shock Gas Strut
AP	730776	P-Clamp, 1/4"

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
AQ	713717	Mounting Bracket, Patio Rail Pulley, Roadside
AR	713718	Mounting Bracket, Patio Rail Pulley, Curbside
AS	715704	Cross Member, 1.13" x 3.00" x 1.25" x 1.25"
AT	691997	Angle Bracket, 2.00" x 2.00" x 2.75"
AU	721498	Angle Bracket, 3.75" x 1.94" x 2.29"

TRIPLE PLAY RAMP DOOR COMPONENTS


DOORS



Callout	Part #	Description
AV	118132	Flat Washer, 1/4"
AW	135834	Flat Washer, 5/16"
AX	214018	Flat Washer, #8
AY	249853	Flat Washer, 1.25"
AZ	122786	Grommet, 1/2" x 5/16"
BA	163492	Rubber Bumper, 3/4" x 1"
BB	334764	Nylon Spacer, 1/2" OD x 1/4"
BC	362350	Button Head Rivet, 1/4"
BD	383359	Pulley, 3/16" Rope, 1 1/4" OD
BE	388846	Plug
BF	692018	Bushing, .750" x .625" x .357"
	703330	Gear Drive Cable Bushing, 1.203" x .625" x .385"
BG	715705	Patio Support Cable Bushing, 438" x 1.000" x .437"
BH	721496	Seal Flap, 1.25" x 1.37" x .35"

TRIPLE PLAY RAMP DOOR COMPONENTS






DOORS



Callout	Part #	Description
BI	118042	Nylon Insert Locking Nut, GR2, 1/4" - 20
	118043	Nylon Insert Locking Nut, 5/16" - 18
	118044	Nylon Insert Locking Nut, 3/8" - 16
	156601	Nylon Insert Locking Nut, M6 x 1.0"
BJ	272458	Nylon Insert Locking Nut, GR2, #6 - 32
BK	119125	Hex Nut, 3/8" - 16
BL	160112	Star Drive Nut, Truss Barrel, 5/16" x 18
BM	120621	Hex Bolt, Tap, GR5, Full Thread, 1/4" - 20
	129662	Hex Bolt, Tap, GR5, Full Thread, 5/16" - 18 x 1 1/4"
	434153	Hex Bolt, Full Thread, M6-1" x 3/4"
BN	132695	Hex Bolt, 3/8" - 16 x 4 1/2"
	178169	Hex Bolt, 5/16" - 18 x 2"
	178671	Hex Bolt, GR5, 3/8"-16 x 4"
	207973	Hex Bolt, 5/16" - 18
	218603	Hex Bolt, GR5, 5/16"-18 x 2"
BO	383356	Button Head Bolt, GR5, 3/8" - 16 x 2 3/4"

TRIPLE PLAY RAMP DOOR COMPONENTS

DOORS



Callout	Part #	Description
BP	266132	Slotted Screw, 1/4" - 20 x 1 1/4"
BQ	307767	Phillips Flat Screw, #6 - 32 x 3/8"
BR	342675	Phillips Pan Head Screw, #6 - 32 x 1 1/8"
BS	345896	Slotted Screw, 1/4" - 20 x 5/8"
BT	369055	Hex Screw, #8 - 32 x 3/8"
BU	688292	Button Head Screw, 5/16" - 18 x 3/4"



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.