



	DIMENSIONS IN INCHES U.N.O. ALL DIMENSIONS OD U.N.O. <u>TOLERANCE OF DIMENSIONS</u> DECIMAL X.XXXX ± 0.010 X.XXX ± 0.030 X.XX ± 0.060 FRACTIONAL ± 1/8 ANGULAR ± 1°	NC56-067		 ...Opportunity Driven...
		DRAWN:	DATE:	
		tbutchko	3/5/2012	
		CUST PART ID:		
		MATERIAL:		
FINISH:		SHEET:		
		2 / 2		



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.