



Troubleshooting Slide-Out Control Boxes 1510000011 and 1510000013

Read, understand and follow these instructions.


© Copyright Power Gear Issued: August 2012

#82-S0526, Rev. 0A

! WARNING

Always make sure that the slide out room path is clear of people and objects before and during operation of the slide out room. Always keep away from the slide out rails when the room is being operated. The gear assembly may pinch or catch on loose clothing.

The 1510000011 and 1510000013 have the same basic control logic, EXCEPT 1510000013 will allow a higher motor amp draw (for a short period of time) when retracting the slide out room up the slide out ramp (normally flush floor models). Contact Lippert Components at www.lci1.com.



1510000011 and 1510000013 6 Pin Connector




Figure 1

! NOTE

Labor Time

Diagnostic time =0.25

Repair time =0.50

Total time =0.75





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.