


RAFTER VII



Rafter7501

Item	Part Number	Description	Notes
1	R00483	Cradle w/ Bracket	Black
	R00483WHT	Cradle w/ Bracket	White
2	R00132W	Backing Plate	White
3	R00711	Bottom Bracket	Black
	R00711WHT	Bottom Bracket	White
4	R00871	Rafter Outer Arm	Satin
	R00871WHT	Rafter Outer Arm	White
5	R00872	Rafter Inner Arm, w/ Linkage	Satin
	R00872WHT	Rafter Inner Arm, w/ Linkage	White
6	R00869	Front End Mounting Assy	Satin
	R00869WHT	Front End Mounting Assy	White
7	R001574	Tip, Front End Mounting Assy	
8	R00870	Knob, Black w/ Nutsert	
9	902310	Ground Support Assy	Satin/Black
	902315	Ground Support Assy	White
10	R00394	Carport Foot	
11	R00721	Strap Assy w/ snaps	
12	R00873	Knob, Black	
13	R001086XXX	Hardware Pack (does not include stakes or bottom brackets)	



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.