


## Installation Instructions


Hold the cam buckle open and pull the strap through to create slack between the cam buckle and the lower hook. To secure the fender to the boat, slide the cam buckle at the top of the fender so the square fence railing fits snugly between the fender and the buckle. It may be necessary to wedge the lip of the buckle between the railing and the furniture on boats where furniture is mounted tightly to the rail as illustrated in figure A. If the furniture is too tight to the rail, try moving a few inches either way to distance the buckle from the fastener that is preventing access behind the rail.



**Figure A**

With the fender hanging from the top rail, attach the vinyl coated hook at the lower end of the strap underneath the edge of the decking. Push the cam buckle in and pull the strap tight. The cam buckle should travel slightly into the slotted area of the fender and securely pinch the top rail as illustrated in figure A.

Three additional attachment points have been included at the middle and very bottom of the Fence Saver II. These may be used as optional fastening points for rougher conditions or added security when leaving the boat unattended for several



**Figure B**

days. Strap, rope or bungee cord may be used through these attachment points to secure the fender to a deck cleat, under the decking, or around the lower rail section if accessible.

# PONTOON BOAT FENCE SAVER

**Keep your Pontoon Safe and Protected!**

The Taylor Made Pontoon Boat Fence Saver fender is designed to easily attach to many styles of pontoon boats. The Fence Saver fender should be placed so it hooks over the top rail and rests against the deck. The special shape of the fender allows it to "bridge" over the railing and fence, protecting the fence from contact with other boats or the dock. Two mounting straps have been included to securely fasten the Fence Saver to the boat. Once installed, the Fence Saver may be left in position eliminating the need to remove and re-attach the fender when docking or rafting. Fender attachment should not be limited to the options listed on the opposite side of this label. The Fence Saver may be attached to other style boats by using the included straps and/or standard rope or bungee cord. An additional fastening point has been built into the fender bottom that may be useful for attachment on some style boats. A proper installation is one that holds the fender in the best position to protect the boat from contact.

## WARRANTY INFORMATION

TAYLOR MAKES NO EXPRESS OR IMPLIED WARRANTIES OTHER THAN WARRANTIES SET FORTH HEREIN, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR FROM ANY COURSE OF DEALING OR TRADE USAGE.

TAYLOR SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF OPPORTUNITY OR BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER LOSS EVEN IF TAYLOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

IN NO EVENT SHALL TAYLOR BE LIABLE FOR ANY AMOUNT IN EXCESS OF THE PURCHASE PRICE PAID.

**#31032**  
**Pontoon Fence**  
**Saver Fender**



0 40011 33032 1

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.