


AeroBlade Edge Technical Specifications

AEROBLADE EDGE RAISED RAIL		Absolute Bar Length		(X) Bar Spacing Min/Max Mounting Width For Products				(Y) Foot Spacing Min/Max Mounting Width On Vehicle			
		(Bar only. No feet)		Min		Max		Min		Max	
Part #	Description	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
7501(B)	Raised Rail Small	29.5	752	23.75	630	27.75	704	33	840	37	940
7502(B)	Raised Rail Medium	32.75	832	27	680	31	780	36	920	40	1020
7503(B)	Raised Rail Large	36	912	30	764	34	864	39.25	1000	43.25	1100
7504(B)	Raised XL	39.75	1012	34	863	38	965	43.25	1100	46.875	1190

NOTE: 'Y' measurements are from inside to inside of vehicle's raised rail.

AEROBLADE EDGE FIXED & FLUSH		Absolute Bar Length		(X) Bar Spacing Min/Max Mounting Width For Products				(Y) Foot Spacing Min/Max Mounting Width On Vehicle			
		(Bar only. No feet)		Min		Max		Min		Max	
Part #	Description	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
7601(B)	Fixed/Flush Small	32	816	26	660	30	760	37	940	40.75	1035
7602(B)	Fixed/Flush Medium	35.25	896	29.25	744	33.25	844	40	1016	43.75	1111
7603(B)	Fixed/Flush Large	38.25	976	32.25	820	36.25	920	43	1092	46.75	1187
7604(B)	Flush Fixed XL	42.38	1076	36.38	924	40.38	1025	46	1169	50	1269

NOTE: Y measurements are center to center of vehicle's fixed point, flush rail or track.





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.