

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS

Note: Part numbers are shown for identification purposes only. Not all parts are available for individual sale.



Callout	Part #	Description
A	808485	Repeater
B	806880	Repeater Dock
C	808489	Alert Indicator
D	808506	Stem Sensor
E	2020002102	Stem Sensor Tool (Separate into two parts)
F	2020003005	Lock Nut Wrench (Optional tool)
G, H & I	812943 Accessory Kit	Charging Cord for Alert Indicator; Suction Cup, optional for Alert Indicator; Mounting Tape Strips, optional for Alert Indicator
J & K	2020001333 Lock & O-Ring Kit	Replacement Stem Sensor O-rings; Lock Nuts for tire stems (Optional usage)

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS



Callout	Part #	Description
A	2020130644	Tire Linc 2.0 Aftermarket AU 4-Stem Sensor Kit with Dock
B	808485	Repeater
C	806880	Repeater Dock
D	2020002102	Stem Sensor Tool (Separate into two parts)
E	808506	Stem Sensors
F	2020003005	Lock Nut Wrench (Optional tool)
G & H	2020001333 Lock & O-Ring Kit	Replacement Stem Sensor O-rings; Lock Nuts for Tire Stems (Optional usage)



LIPPERT
COMPONENTS

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS



Callout	Part #	Description
A	2020130643	Tire Linc 2.0 Aftermarket AU 4-Stem Sensor Kit without Dock
	2020130723	Tire Linc 2.0 OEM AU 4-Stem Sensor Kit without Dock
B	808485	Repeater
C	808506	Stem Sensors
D	2020000305	Stem Sensor Tool (Separate into two parts)
E	2020003005	Lock Nut Wrench (Optional tool)
F & G	2020001333 Lock & O-Ring Kit	Replacement Stem Sensor O-rings; Lock Nuts for Tire Stems (Optional usage)



LIPPERT
COMPONENTS

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS



Callout	Part #	Description
A	2020130630	Tire Linc 2.0 Aftermarket AU 2-Stem Sensor Kit with Dock
B	808485	Repeater
C	806880	Repeater Dock
D	2020002102	Stem Sensor Tool (Separate into two parts)
E	808506	Stem Sensors
F	2020003005	Lock Nut Wrench (Optional tool)
G & H	2020001333 Lock & O-Ring Kit	Replacement Stem Sensor O-rings; Lock Nuts for Tire Stems (Optional usage)

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS



Callout	Part #	Description
A	2020130627	Tire Linc 2.0 Aftermarket AU 2-Stem Sensor Kit without Dock
	2020130722	Tire Linc 2.0 OEM AU 2-Stem Sensor Kit without Dock
B	808485	Repeater
C	808506	Stem Sensors
D	2020002102	Stem Sensor Tool (Separate into two parts)
E	2020003005	Lock Nut Wrench (Optional tool)
F & G	2020001333 Lock & O-Ring Kit	Replacement Stem Sensor O-rings; Lock Nuts for Tire Stems (Optional usage)

TIRE LINC® 2.0 TYRE PRESSURE & TEMPERATURE MONITORING SYSTEM COMPONENTS (AU)

ELECTRONICS



Callout	Part #	Description
A	2020130646	Tire Linc 2.0 Aftermarket AU Alert Indicator Kit with Accessories
B	808489	Alert Indicator
C, D & E	812943 Accessory Kit	Mounting Tape Strips, optional for Alert Indicator; Charging Cord for Alert Indicator; Suction Cup, optional for Alert Indicator;



Callout	Part #	Description
A	2020130645	Tire Linc 2.0 Aftermarket AU Stem Sensor 1-Pack Kit
B	808506	Stem Sensor



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.