

PERIMETER



INDUSTRIES

LIFELINE CUSHIONS



- Makes your lifelines a better backrest.
- Polyester covered, not bare foam!
- Inner cushion provides a comfortable, yet sturdy backrest.
- Will not discolor, fade or rot in the sun, and cleans easily with common liquid soap.

***Because Your
Boat
Deserves the Best!***



TAYLOR MADE PRODUCTS

65 Harrison Street, Gloversville, NY 12078

A Member of The Taylor Made Group

(800)225-6636 • www.taylormadeproducts.com

© Taylor Made is a registered trademark of the Nelson A. Taylor Co., Inc.

Installation:

- ① Unscrew swage stud from lifeline turnbuckle. Simply thread your lifeline through the center of these polyester covered foam cushions.
- ② Reattach swage stud to lifeline turnbuckle.
- ③ Spray down occasionally with a water hose to remove dust and dirt. Any common liquid soap will remove stubborn dirt.

Cutting to length:

- ① Using a sharp knife, cut through the polyester textile and inner foam cushion to your desired length.
- ② Pull and cut back the two bundles of thread that run the circumference of the tubular textile. Because of the way the textile is woven, it will not unravel. However, in order to keep the textile looking tidy, you may wish to use a hot blade to melt the edges.
- ③ Pull the textile back a few inches and trim the foam edges similar to the end you cut off.
- ④ The end of the textile can then be sewn or melted together similar to the end that was cut off.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.