




JT's STRONG ARM



JT's Strong Arm™ Installation and Owner's Manual (For Aftermarket Applications)

Table of Contents

Introduction	2
Safety	2
Parts List	3
Resources Required	4
Preparation	4
Installation	4
Operation	10
Maintenance	10
Hydraulic Jack Adapter Lugs	11
This is an optional kit to be used when installing JT Strong Arm to units with hydraulic jacks.	11
Parts List	11
Resources Required	11
Preparation	11
Installation	11
Notes	12

JT Strong Arm Aftermarket Kits

Part #	Description
191023	Jack Stabilizer, 5th Wheel - 58" or more between front jacks
191024	Jack Stabilizer, 5th Wheel, Short - Less than 58" between front jacks



JT's Strong Arm™

Installation and Owner's Manual

(For Aftermarket Applications)

Introduction

The JT Strong Arm® Stabilizer System is a locking bracket system used to stabilize and eliminate chassis movement in travel trailers and 5th Wheels using a triangulation system attached to the coach's landing gear or jacks and frame. The JT Strong Arm Stabilizer system is intended to eliminate chassis movement in travel trailers and 5th Wheels. It should not be used for any other purpose.

Additional information about this product can be obtained from lci1.com/support or by downloading the free LippertNOW. The app is available on Apple App Store® for iPhone® and iPad® and also on Google Play™ for Android™ users.

iPhone®, and iPad® are registered trademarks of Apple Inc.

Google Play™ and Android™ are trademarks of Google Inc.

Safety

Read and fully understand all instructions within this manual and adhere to all safety labels.

This manual provides general instructions. Many variables can change the circumstances of the instructions, i.e., the degree of difficulty, operation and ability of the individual performing the instructions. This manual cannot begin to plot out instructions for every possibility, but provides the general instructions, as necessary, for effectively interfacing with the device, product or system. Failure to correctly follow the provided instructions may result in death, serious personal injury, severe product and/or property damage, including voiding of the Lippert limited warranty.

⚠ WARNING

FAILURE TO ACT IN ACCORDANCE WITH THE FOLLOWING MAY RESULT IN DEATH, SERIOUS PERSONAL INJURY OR SEVERE PRODUCT OR PROPERTY DAMAGE.

⚠ WARNING

NEVER LIFT THE UNIT COMPLETELY OFF THE GROUND. LIFTING THE UNIT SO THE WHEELS ARE NOT TOUCHING THE GROUND WILL CREATE AN UNSTABLE AND UNSAFE CONDITION.

⚠ WARNING

THE TRAILER MUST BE SUPPORTED PER THE MANUFACTURER'S RECOMMENDATIONS BEFORE WORKING UNDERNEATH. FAILURE TO DO SO MAY RESULT IN DEATH, SERIOUS PERSONAL INJURY OR SEVERE PRODUCT OR PROPERTY DAMAGE.

⚠ WARNING

WHEN USED WITH AN AUTOMATIC LEVELING SYSTEM, STRONG ARMS MUST BE UNLOCKED BEFORE RETRACTING THE JACKS. FAILURE TO DO THIS MAY RESULT IN SERIOUS PERSONAL INJURY OR SEVERE PRODUCT OR PROPERTY DAMAGE.

⚠ CAUTION

ALWAYS WEAR EYE PROTECTION WHEN PERFORMING SERVICE OR MAINTENANCE TO THE TRAILER. OTHER SAFETY EQUIPMENT TO CONSIDER WOULD BE HEARING PROTECTION, GLOVES AND POSSIBLY A FULL FACE SHIELD, DEPENDING ON THE NATURE OF THE SERVICE.

⚠ CAUTION



MOVING PARTS CAN PINCH, CRUSH OR CUT. KEEP CLEAR AND USE CAUTION.

JT's Strong Arm™

Installation and Owner's Manual

(For Aftermarket Applications)

Parts List



Jack Stabilizer, 5th Wheel 58" or more between front jacks - 191023			
Letter	Part #	Description	Qty
A	191014	Outer Stabilizer; 1 1/4" O.D.	6
B	191016	Front Electric Landing Jacks "Warning Sticker" Label	1
C	191015	Inner Stabilizer; 1" O.D.	6
D	191018	Clevis for Front Electric Landing Jacks	2
E	191012	T-Bolt; 3/8" - 16 x 3/4"	6
F	191022	Flanged Bushing, 3/8" I.D. x 1/2" O.D. x 5/32"	4
G	118044	Nylon Locking Nut; 3/8" - 16	30
H	135840	Flat Washer; 3/8"	48
I	155004	Hex Bolt; 3/8" - 16 x 1 1/2"	18
J	191011	Swing Bolt; 3/8" - 16 x 4"	4
K	191010	Swing Bolt; 3/8" - 16 x 1 1/4"	6
L	191017	Lifting Handles Bolt; 3/8" - 16	2
M	191019	Heavy Hex Nut; 3/8" - 16	2
N	191013	Stiffening Pad; 2 3/4" x 1 1/4"	6
O	191020	Spacer Mount, 4 1/2" x 1 1/2" x 1 1/2"	4
P	191021	Hex Bolt; 3/8" - 16 x 1"	8

Jack Stabilizer, 5th Wheel, Short Less than 58" between front jacks - 191024			
Letter	Part #	Description	Qty
A	194468	Short Outer Stabilizer; 1 1/4" O.D.	2
B	191014	Outer Stabilizer; 1 1/4" O.D.	4
C	194469	Short Inner Stabilizer; 1" O.D.	2
D	191015	Inner Stabilizer; 1" O.D.	4
E	191012	T-Bolt; 3/8" - 16 x 3/4"	6
F	191022	Flanged Bushing, 3/8" I.D. x 1/2" O.D. x 5/32"	4
G	191016	Front Electric Landing Jacks "Warning Sticker" Label	1
H	118044	Nylon Locking Nut; 3/8" - 16	30
I	135840	Flat Washer; 3/8"	48
J	155004	Hex Bolt; 3/8" - 16 x 1 1/2"	18
K	191010	Swing Bolt; 3/8" - 16 x 1 1/4"	6
L	191011	Swing Bolt; 3/8" - 16 x 4"	4
M	191017	Lifting Handles Bolt; 3/8" - 16	2
N	191019	Heavy Hex Nut; 3/8" - 16	2
O	191013	Stiffening Pad; 2 3/4" x 1 1/4"	6
P	191020	Spacer Mount, 4 1/2" x 1 1/2" x 1 1/2"	4
Q	191021	Hex Bolt; 3/8" - 16 x 1"	8
R	191018	Clevis for Front Electric Landing Jacks	2

*Two arms are 3" shorter



JT's Strong Arm™

Installation and Owner's Manual

(For Aftermarket Applications)

Resources Required

- Tape measure
- Felt-tip black marker
- Hammer
- Center punch
- Electric or cordless drill or screw gun
- 1/8" drill bit (for pilot holes)
- 5/16" drill bit
- 3/8" drill bit
- 1/2" "Uni-bit," or step bit, preferred—standard 1/2" drill bit acceptable
- Countersink bit (for deburring)
- 9/16" deep socket and ratchet
- 9/16" box end wrench
- 5/8" box end wrench
- 1 1/16" box end wrench
- Locking pliers
- 3"-4" C-Clamp
- White grease
- Safety glasses
- Face shield
- Squeegee

Preparation

1. Make sure to park the trailer on solid, level ground.
2. Clear all jack landing locations of debris and obstructions.
3. Locations should be free of depressions.
4. When parking trailer on extremely soft surfaces, utilize load distribution pads under each jack.
5. People and pets should be clear of trailer while operating leveling system.

Installation

1. For 2006 or later telescoping jacks:
 - A. Replace existing 3/8" jack pad bolt with 3/8" - 16 x 4" swing bolt.
 - B. Use 3/8" - 16 nut to secure. Insert a 3/8" - 16 x 1 1/4" swing bolt with the tab pointing to the rear of the chassis.
 - C. Secure with a 3/8" washer and 3/8" - 16 Nyloc® nut.
 - D. Prepare T-Bolts and stabilizer tubes as described in step 12, except the inner tube should be set at 1" instead of 5".

E. After fully retracting rear telescoping jacks, attach the clevis end of the stabilizer inner tube to the swing bolt tab on the rear side of the jack using a 3/8" - 16 x 1 1/2" bolt with a 3/8" washer on the top and bottom of the tab and a 3/8" - 16 Nylon Locking nut.

F. Tighten nut until tight.

G. Repeat steps 1A-1F on opposite side.

2. Locate a cross-member rearward of the rear jacks at a minimum of 6" to a maximum of 18".

A. Under front half of chassis, locate a cross-member or center compartment with a steel floor from 6"-18" from front of electric leveling jacks.

NOTE: If unable to locate a suitable mounting location at the front or rear of chassis, contact LCI customer service.

3. At the front of the chassis, measure the inside distance between the front electric leveling jacks just below the frame of the chassis.

A. If measurement between front electric jacks is 58" to 66" and the chassis is insulated and has a center compartment with a steel floor located between the front jacks, refer to step 4.

B. If measurement between the front jacks is 58" to 66" and the chassis is uninsulated with a C-Channel cross-member, refer to step 5.

C. If the measurement between the front jacks is 66" or longer and the chassis is uninsulated with a C-Channel cross-member, refer to step 6.

D. If the measurement between the front jacks is 66" or longer and the chassis is insulated and has a center compartment with a steel floor located between the front jacks, refer to step 7.

E. If the measurement between the front jacks is 66" or longer and the chassis is insulated and the cross-member is constructed of tubular steel, refer to step 4.

F. If the measurement between the front jacks is less than 58", use kit [#191024](#).

JT's Strong Arm™ **Installation and Owner's Manual** **(For Aftermarket Applications)**

4. Mark the bottom of the center compartment centered between the front electric jacks. Mark the center of one of the stiffening pads between the mounting holes.

A. Align the center marks on the stiffening pad and the bottom of the center compartment and place the stiffening pad $\frac{1}{4}$ " from the front edge of the center compartment.

B. Mark the center of each mounting hole in the stiffening pad on the bottom of the center compartment and center-punch the marks.

CAUTION

REMOVE PERSONAL PROPERTY AND VALUABLES FROM THE CENTER COMPARTMENT TO PREVENT POSSIBLE DAMAGE OCCURRING DURING DRILLING.

C. To prevent accidental damage to personal property, clear the center compartment of any valuables.

D. Drill a $\frac{1}{8}$ " pilot hole at each mounting hole location.

E. Drill $\frac{3}{8}$ " mounting holes. Use a countersink bit to deburr the inside of the holes.

F. Sandwich the floor of the center compartment between two stiffening pads.

I. Insert two $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolts, two $\frac{3}{8}$ " SAE flat washers and two $\frac{3}{8}$ " - 16 Nyloc® nuts.

II. Tighten nuts enough to ensure needing a screwdriver for leverage to pivot swing bolts (**Fig.1**).

5. Mark the bottom of the cross-member centered between the front electric jacks. Mark the center of one of the stiffening pads between the mounting holes.

A. Align the center marks on the stiffening pad and the bottom of the cross-member, clamp pads with a pair of locking pliers or C-Clamps.

B. Drill $\frac{3}{8}$ " mounting holes. Use a countersink bit to deburr inside of holes.

C. Sandwich the floor of the center compartment between two stiffening pads.

I. Insert two $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolts, two $\frac{3}{8}$ " SAE flat washers and two $\frac{3}{8}$ " - 16 Nyloc® nuts

II. Tighten nuts enough to ensure needing a screwdriver for leverage to pivot swing bolts (**Fig.1**).

6. From the inside of both front jacks, measure toward the center of the cross-member 30" and place a mark. Mark the center of two of the stiffening pads between the mounting holes.

A. Align the center marks on the stiffening pad and the bottom of the cross-member and clamp with a pair of locking pliers or C-Clamp.

B. Drill the mounting holes with a $\frac{3}{8}$ " bit.

C. Secure the stiffening pads to the bottom of the cross-member with two $\frac{3}{8}$ " x 1 $\frac{1}{4}$ " swing-bolts (P/N 191010), two $\frac{3}{8}$ " x 1 $\frac{1}{2}$ " bolt (P/N 155004), four $\frac{3}{8}$ " washers (P/N 135840), and four $\frac{3}{8}$ " - 16 locking nuts (P/N 118044).

NOTE: The swing bolts should be inserted into the mounting holes located closest to the electric jacks.

I. Tighten nuts enough to ensure needing a screwdriver for leverage to pivot swing bolts (**Fig.1**).




Fig.1

JT's Strong Arm™ Installation and Owner's Manual (For Aftermarket Applications)

7. From the inside of both front jacks, measure toward the center of the center compartment 30" and place a 2" mark $\frac{1}{4}$ " from the front edge of the compartment.

A. Mark the center of two of the stiffening pads between the mounting holes.

B. Align the center marks on the stiffening pads and the bottom of the center compartment and place the stiffening pad $\frac{1}{4}$ " from the front edge of the compartment.

C. Mark the center of each mounting hole in the stiffening pads on the bottom of the center compartment, then center-punch the marks.

CAUTION

REMOVE PERSONAL PROPERTY AND VALUABLES FROM THE CENTER COMPARTMENT TO PREVENT POSSIBLE DAMAGE OCCURRING DURING DRILLING.

D. To prevent accidental damage to personal property, clear the center compartment of any valuables.

E. Drill a $\frac{1}{8}$ " pilot hole at each mounting hole location. Drill $\frac{3}{8}$ " mounting holes. Use a countersink bit to deburr the inside of the holes.

F. Sandwich the floor of the center compartment between the stiffening pads.

G. Secure the pads using two $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolts, two $\frac{3}{8}$ " x 1 $\frac{1}{2}$ " bolts, four $\frac{3}{8}$ " washers and four $\frac{3}{8}$ " - 16 locking nuts.

H. The swing bolts should be inserted into the mounting holes located closest to the electric jacks.

I. Tighten nuts enough to ensure needing a screwdriver for leverage to pivot swing bolts.

8. Insert a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolt into a spacer mount and secure with a $\frac{3}{8}$ " washer and $\frac{3}{8}$ " - 16 Nylon Locking nut.

A. From the inside of both front jacks, measure toward the center of the cross-member 27 $\frac{3}{4}$ " and place a mark. Align one of the short edges of the spacer mount with the mark keeping the swing bolt toward the center of the chassis.

B. Mark the center of the mounting holes, then center punch them.

C. Drill $\frac{1}{8}$ " pilot holes at the four mounting hole locations, then re-drill the holes located closest to the electric jacks to $\frac{5}{16}$ " on both sides of chassis.

D. Tap the $\frac{5}{16}$ " holes with either a $\frac{3}{8}$ " - 16 tap or a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt. Lubricate tap as needed.

E. Remove tap or bolt and secure spacer mount with a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt, taking care to keep the remaining pilot hole centered in the mounting hole of the spacer mount. Tighten bolt securely.

F. Drill remaining pilot hole to $\frac{5}{16}$ " and insert a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt and tighten (**Fig.2**).




Fig.2

JT's Strong Arm™ **Installation and Owner's Manual** **(For Aftermarket Applications)**

G. Repeat steps 8A-8F on opposite side of chassis.

9. Make sure the adjustment holes in each jack leg above the foot pad pin are $\frac{1}{2}$ " diameter. If not, re-drill hole with a step bit or standard $\frac{1}{2}$ " bit, then deburr holes with a countersink bit.

A. Insert a $\frac{3}{8}$ " I.D. x $\frac{1}{2}$ " O.D. flanged bushing into the second from the bottom holes in each jack leg.

B. Apply a thin layer of white grease to the shaft of a $\frac{3}{8}$ " - 16 x 4" swing bolt and the flanges of the bushings.

C. For each jack leg, do as follows:

I. Align the mounting holes of the electric jack clevis with the bushings from the rear of the jack leg and insert the swing bolt through both sides with the shoulder and $\frac{3}{8}$ " washer on the inside of the jack leg.

II. Apply a thin layer of grease to a $\frac{3}{8}$ " washer and place on outside of clevis, over the swing bolt.

III. Secure the swing bolt and clevis with a $\frac{3}{8}$ " - 16 grade A heavy hex nut.

IV. Tighten heavy hex nut enough to eliminate side play (**Fig.3**).




Fig.3

D. Thread a $\frac{3}{8}$ " - 16 nut ("Silver Bullet") lifting handle onto the outside of the swing bolt. Tighten nut lifting handle against the $\frac{3}{8}$ " - 16 heavy hex nut (**Fig.3**).

NOTE: For chassis that are constructed with "I" or "H" beam main rails (front-to-back) and are uninsulated, go to step 10. For chassis that are constructed with "I" or "H" beam main rails or tubular frames and/or insulated, go to step 12.

10. From the rear side of an electric jack leg, measure 30" and place a mark on the bottom of each main rail. Measure the bottom flange of each main rail, then divide that measurement by four to determine the center location of the mounting hole.

A. Center punch the intersection of the lines, then drill a $\frac{1}{8}$ " pilot hole.

B. Re-drill out the pilot hole to $\frac{3}{8}$ " and deburr with a countersink bit.

C. Secure a stiffening pad to the bottom of the main rail flange using a $\frac{3}{8}$ " - 16 x $1\frac{1}{4}$ " swing bolt, a $\frac{3}{8}$ " washer and a $\frac{3}{8}$ " - 16 Nylon Locking nut.

NOTE: The edge of the stiffening pad should be parallel to the edge of the main rail flange.

D. Drill remaining mounting hole and secure with a $\frac{3}{8}$ " - 16 x $1\frac{1}{2}$ " bolt, $\frac{3}{8}$ " washer and $\frac{3}{8}$ " - 16 Nylon Locking nut (**Fig.4**).




Fig.4

JT's Strong Arm™ Installation and Owner's Manual (For Aftermarket Applications)

E. Repeat steps 10A-10D for opposite side of the chassis.

11. Measure from the rear side of the electric jack leg 27 3/4" and place a mark on the bottom of the main rails. Assemble a spacer mount.

A. Using the spacer mount as a template, mark the mounting holes by aligning one short edge with the 27 3/4" mark.

NOTE: The spacer mount should be parallel to the outside of the main rail flange.

B. Center punch and drill 1/8" pilot holes at each mounting hole location.

C. Re-drill the holes located closest to the front jacks to 5/16" on both sides of the chassis.

D. Tap the 5/16" holes with either a 3/8" - 16 tap or a 3/8" - 16 x 1" self-tapping bolt. Lubricate tap as needed.

E. Secure spacer mount to bottom of main rail flange with a 3/8" - 16 x 1" self-tapping bolt, taking care to keep the remaining pilot hole centered in the mounting of the spacer mount. Tighten bolt securely.

F. Re-drill the remaining pilot hole to 5/16". Then insert a 3/8" - 16 x 1" self-tapping bolt and tighten.




Fig.5

G. Repeat steps 11A-11F for opposite side of the chassis.

12. Apply white grease to the threads of two T-Bolts, then partially thread them into the top holes of the outer stabilizer tubes.

A. Remove inner stabilizer tube from assembly and discard the plastic shipping bag.

B. Reassemble stabilizer tubes with the inner tube sticking out past the end of the outer tube by 5". Tighten T-Bolts until snug (**Fig.6**).




Fig.6

13. To ensure proper installation, make sure the warning labels are facing outward and right-side up. The T-Bolts should be on the top side of the stabilizers.

A. Apply a thin layer of white grease to swing bolt tabs.

B. Attach clevis of outer stabilizer tube to the swing bolt tab under center of chassis with a 3/8" - 16 x 1 1/2" bolt, 3/8" washer and 3/8" - 16 Nylon Locking nut.

C. Tighten nut until the stabilizer tubes swing to the ground with resistance.

D. Attach clevis of inner stabilizer tube to swing bolt tab on jack leg with a 3/8" - 16 x 1 1/2" bolt, 3/8" washer and 3/8" - 16 Nylon Locking nut. Loosen T-Bolt if needed.

E. Repeat steps 13A-13D for opposite side of the chassis.

JT's Strong Arm™

Installation and Owner's Manual

(For Aftermarket Applications)

14. Prepare stabilizer tube as described in step 12. To ensure proper installation, make sure the warning labels are facing outward and right-side up. The T-Bolts should also be on the top side of the stabilizers.

- A.** Apply a thin layer of white grease to swing bolt tabs.
- B.** Attach clevis of outer stabilizer tube to the swing bolt tab under main rail of chassis with a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{2}$ " bolt, $\frac{3}{8}$ " washer and $\frac{3}{8}$ " - 16 Nylon Locking nut.
- C.** Tighten nut until the stabilizer tubes swing to the ground with resistance.
- D.** Attach clevis of inner stabilizer tube to tab on electric jack clevis with a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{2}$ " bolt, $\frac{3}{8}$ " washer and $\frac{3}{8}$ " - 16 Nylon Locking nut. Loosen T-Bolt if needed.
- E.** Repeat steps 14A-14D for opposite side of the chassis.

NOTE: For chassis with rear scissor jacks, go to step 15. For chassis with telescoping rear jacks, go to step 16.

15. Starting with one of the rear scissor jacks, remove the existing lower, outside pivot bolt. Replace pivot bolt with a $\frac{3}{8}$ " - 16 x 4" swing bolt.

- A.** Install swing bolt from back-to-front with the shoulder of the swing bolt to the rear side of the jack.
- B.** Place $\frac{3}{8}$ " washer and a $\frac{3}{8}$ " - 16 Nyloc® nut onto the threaded end of the swing bolt. Tighten nut enough so that the swing bolt will only pivot by using a screwdriver for leverage. Make sure the swing bolt tab is positioned horizontally.
- C.** Prepare T-Bolts and stabilizer tubes as described in step 12, except the inner tube should be set at 1" instead of 5".
- D.** After fully retracting rear scissor jacks, attach the clevis end of the stabilizer inner tube to the swing bolt tab on the rear side of the jack using a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{2}$ " bolt with a $\frac{3}{8}$ " washer on the top and bottom of the tab and a $\frac{3}{8}$ " - 16 Nylon Locking nut. Tighten nut until tight.
- E.** Repeat steps 15A-15D for opposite side of the chassis.

NOTE: If scissor jacks are less than 2" wide, washers will be necessary on the swing bolt because the threads may not be long enough.

16. Drill a $\frac{3}{8}$ " hole centered in the telescoping channel and 1" up from the end.

A. For 2006 or later telescoping jacks:

I. Replace existing $\frac{3}{8}$ " jack pad bolt with $\frac{3}{8}$ " - 16 x 4" swing bolt. Use $\frac{3}{8}$ " - 16 nut to secure swing bolt.

II. Insert a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolt with the tab pointing to the rear of the chassis. Secure with a $\frac{3}{8}$ " washer and $\frac{3}{8}$ " - 16 Nylon Locking nut. Tighten as described in step 10.

III. Prepare T-Bolts and stabilizer tubes as described in step 12, except the inner tube should be set at 1" instead of 5".

IV. After fully retracting rear telescoping jacks, attach the clevis end of the stabilizer inner tube to the swing bolt tab on the rear side of the jack using a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{2}$ " bolt with a $\frac{3}{8}$ " washer on the top and bottom of the tab and a $\frac{3}{8}$ " - 16 Nylon Locking nut. Tighten nut until tight.

V. Repeat steps 16A.I-16A.IV for opposite side of the chassis.

B. For chassis that are constructed with C-Channel rear cross-members and uninsulated, go to step 17.

C. For chassis that are constructed with C-Channel rear cross-members or tubular frames and/or insulated, refer to step 18.

17. Attach a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " swing bolt to the clevis end of the stabilizer outer tube with a $\frac{3}{8}$ " - 16 Nylon Locking nut and $\frac{3}{8}$ " washer. Tighten nut enough to allow swing bolt to point upwards.

A. Rotate stabilizer tube toward center of chassis and up to cross-member identified in step 2.

B. Mark where center of swing bolt meets the center of the cross-member front-to-back on the bottom of the cross-member.

C. Align a stiffening pad with the outer hole centered on the mark for the center of the swing bolt. Clamp the stiffening pad to the cross-member with a pair of locking pliers and drill mounting holes with a $\frac{3}{8}$ " bit.

JT's Strong Arm™

Installation and Owner's Manual

(For Aftermarket Applications)

D. Secure stiffening pad to the cross-member with a $\frac{3}{8}$ " - 16 x 1 $\frac{1}{4}$ " bolt, $\frac{3}{8}$ " - 16 Nylon Locking nut and $\frac{3}{8}$ " washer in the inside mounting hole.

E. After removing the locking pliers, attach swing bolt to remaining mounting hole with a $\frac{3}{8}$ " - 16 Nylon Locking nut and washer.

F. Repeat steps 17A-17E for opposite side of the chassis.

18. Prepare spacer mounts as described in step 8. Rotate stabilizer tubes toward center of chassis and upward to cross-member identified in step 2.

A. Using the spacer mount as a template, mark the mounting holes by aligning one short edge with the center of the cross-member. Make sure the spacer mount is parallel to the edge of the rear cross-member.

B. Center punch and drill $\frac{1}{8}$ " pilot holes at each mounting hole location.

C. Drill $\frac{1}{8}$ " pilot holes at the four mounting hole locations, then re-drill the holes located closest to the electric jacks to $\frac{5}{16}$ " on both sides of chassis.

D. Tap the $\frac{5}{16}$ " holes with either a $\frac{3}{8}$ " - 16 tap or a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt. Lubricate tap as needed.

E. Secure spacer mount to bottom of rear cross-member with a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt, taking care to keep the remaining pilot hole centered in the mounting of the spacer mount. Tighten bolt securely.

F. Re-drill the remaining pilot hole to $\frac{5}{16}$ ". Then insert a $\frac{3}{8}$ " - 16 x 1" self-tapping bolt and tighten.

G. Repeat steps 18A-18F for opposite side of chassis.

19. Place Warning Label in any available location that is visible while operating electric leveling jack switch.

A. Clean mounting surface thoroughly.

B. Remove backing from label and adhere to mounting surface using a squeegee or similar tool.

Operation

1. Level your trailer side-to-side.

2. Lower the front of the trailer $\frac{3}{4}$ " lower than the rear.

3. Lower and set rear jacks evenly.

4. Tighten the T-Bolts on the two rear Strong Arm Jack Stabilizers.

5. Raise the front of the trailer to make it level front-to-back.

6. Tighten T-Bolts on the four front Strong Arm Jack Stabilizers.

7. Briefly press the electric jack switch so the jacks slightly lift the front of the trailer. This eliminates the play (movement) at the bolts and bolt holes between the stabilizers and the trailer.

Maintenance


Periodically wash the strong arms with water to remove any salt or debris. Then wipe dry with a clean, dry cloth.

JT's Strong Arm™ **Installation and Owner's Manual** **(For Aftermarket Applications)**

Hydraulic Jack Adapter Lugs

This is an optional kit to be used when installing JT Strong Arm to units with hydraulic jacks.

Parts List



Hydraulic Jack Adapter Lugs (314592)			
Letter	Part #	Description	Qty
A	196233	Hydraulic Jack Adapter Lugs	2
B	427963	Screw	2

Resources Required

- Cordless or electric drill or screw gun
- Appropriate drive bits
- Appropriate drill bits
- Bolts
- Liquid thread locker
- Non-permanent marking device

NOTE: For most applications, three (3) kits (six (6) lugs) will be necessary unless repairing/reinstalling an individual footpad.

Preparation

Prior to installation, prepare surface of footpad for lug installation. Wipe footpad clean of hydraulic fluid.


Each footpad requires a different number of lugs.

Footpad	Number of Lugs
Front	2
Back	1

Installation

1. Measure 1 1/4" from the edge of the footpad inward and onto one of the star points on top of the footpad. The front face of the lug will be placed here with the back of the lug continuing to move inward.
2. Use a non-permanent marking device (such as a pencil) to mark lug locations.
3. Using a cordless or electric drill or screw gun, drill a 3/8" hole under the footpad.
4. Bolt lugs to footpad using a liquid thread locker on the bolts.

NOTE: The best practice is to bolt footpads using provided screws. However, users with an advanced skill level and using best safety and welding practices may choose to weld the lugs and footpads.



NOTE: Fourth back footpad not shown.



LIPPERT
COMPONENTS®

JT's Strong Arm™ Installation and Owner's Manual (For Aftermarket Applications)

Notes



Manual information may be distributed as a complete document only, unless Lippert Components provides explicit consent to distribute individual parts.

All manual information is subject to change without notice. Revised editions will be available for free download at lci1.com. Manual information is considered factual until made obsolete by a revised version.

Please recycle all obsolete materials and contact Lippert Components with concerns or questions.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.